



For iPhone 4/4S

USER MANUAL

Welcome

Thank you for purchasing the iPower® FM for iPhone 4/4S. Please read the user manual carefully before use.

iPower® FM.
Drive, listen, charge... wirelessly.

Visit www.ipowerup.net for more FAQ and support



iPower® FM

- (1) LED Indicators & On/Off
- (2) Micro USB input port
- (3) Camera opening
- (4) On/Off button
- (5) Channel buttons
- (6) Speaker Holes

Specifications

Product name: iPower® FM
Cell type: Li-polymer battery
Input: DC 5.0V 500mAh
Output: DC 5.0V 1000mAh
Capacity: 1600mAh
Dimension: 2.4in x 4.8in x 0.58in
Weight: 2.7oz
Compatibility: iPhone 4/4S
Standby time: Up to 200 hrs
Talk time: Up to 4.5 hrs 4G, up to 5.5 hrs 3G
Internet use: up to 3.8 hrs 3G, up to 6.5 hrs Wi-Fi
Audio Play: up to 26 hrs
Video Play: up to 5.5 hrs
Hotspot usage: up to 3 hrs (2 devices)

Charging Instructions:

1. Use the included micro-USB cable to charge the iPower® FM for the first time from USB port or wall charger.
2. When you charge the iPower device with the iPhone inserted and it will charge both devices. In this operation, the power source will charge your iPhone first until full, then will charge the iPower. You can always charge the iPower FM independently also. LED light indicators light up progressively when iPower FM is charging. When all five lights are illuminated (no flickering) both devices are fully charged.
3. Press and hold the ON/OFF button to activate the charge from the iPower case. When case is charging the iPhone, the LED's will light up progressively. After pre-charging your iPower FM and phone, use the ON/OFF button to utilize the charge for efficient long-term usage when mobile.

Package Contents Included

- iPower® FM for iPhone 4/4S
- Micro USB Cable
- User Manual

FM Transmitter Instructions

To use the FM transmitter, press the CH key. The FM indicator light will go on, press CH key again to choose one of the four transmitter frequency points 88.1, 88.5, 88.9, 89.3MHz. Then tune the car FM settings to the corresponding receiving frequency channel. If there is no music signal within one minute, the FM transmitter function will turn off to save power. At times, there may be static interference due to FM frequency saturation.

Battery Consumption

When iPhone and iPower FM are connected to any power source, the power source charges the iPhone first. When the phone is charged up to 80%, the power source then charges the iPower case. If the power source is cut off iPower FM becomes the main power supply (if the unit is in charge mode) until it is less than 5%, then the power is supplied by your iPhone.

Sync

When iPhone is inserted in iPower FM, you are able to synchronize your iPhone with iTunes or other applications without removing the iPhone from the iPower FM case. It is recommended to use the original included micro USB cable, as other cables may not work properly.

LED lights Indication

Press the button to indicate case's power status.

- LED 1-5 Lit= 100%
- LED 1-4 Lit= 80%
- LED 1-3 Lit= 60%
- LED 1-2 Lit= 40%
- LED 1 Lit= 20%
- LED 1 flashing= Less than 20%

On & Off Button

To turn on the iPower FM, press the button and the iPhone will make an audible sound that you're charging. To turn off the iPower, hold down the On/Off button 3 seconds and release. To ensure you're not still charging check your iPhone battery, it should not show a charging icon.

Performing this feature will allow your iPower FM to provide full backup power when needed.

For best results, charge your iPhone in the iPower FM case nightly, and only activate your iPower FM when your iPhone's battery power is at the halfway point or lower.

Camera Flash: When using flash on the camera, for best results, remove the iPhone from the iPower FM.

FAQ

What are the best charging methods?

Connect using USB cable that came with iPower FM. Can be plugged in to your computer or any wall plug power source.

How many charge cycles do I get with iPower FM?

Rechargeable for over 500 cycles avg.

What do I do when there is static? Static interference may occur from FM frequency saturation, try changing the FM station.

Will I double battery life? We cannot guarantee you will double the battery life. The amount of additional power depends on a variety of factors different for every user.

Warning

Read all instructions and warnings prior to using this product. Failure to do so could result in fire, explosion, electrical shock, or other hazard causing serious and/or fatal injury, and or product damage.

1. Do not modify, disassemble, open, drop, crush, puncture, force, or shred the product.
2. Do not expose product to rain or water.
3. Keep away from open flame
4. Keep away from high voltage devices.
5. This product is not a toy, keep away from children. Ensure that all persons who use this product read all instructions and warnings.
6. Only use the adapter with outlet voltage of 4.75V-5.25V or computer USB port to charge the product.
7. Do not force the plug in charging ports. Doing so may cause permanent damage to the ports, device, or cable.
8. Do not wash with harsh soaps, detergents, or chemicals.
9. Over an extended period of non usage, the iPower will begin to discharge less than 5% overtime. Charge at least once every three months when not in use.
10. Misuse of this product may result in damages that are not covered in the one year limited warranty.
11. Please see the One Year Limited Warranty on the back of this manual for further information.
12. All parts of this product including its accessories are limited to the use of the product.
13. The developer and manufacturer of this product have the right of interpretation, determination, and revision of any and all of the above.